

2008 Ford Mustang
CABIN AIR FILTERS Cabin Air Filter - Mustang

CABIN AIR FILTERS

Cabin Air Filter - Mustang

REMOVAL & INSTALLATION

NOTE: Some 2007 and later models may not be equipped with a cabin air filter.

CABIN AIR FILTER


Removal & Installation

The cabin air filter is located under the RH cowl vent screen.

1. Remove 2 wiper arm nut covers and 2 nuts. Remove 2 wiper pivot arms. See **Fig. 1**.
2. Remove 2 RH cowl vent screen pin-type retainers. See **Fig. 1**. Remove RH cowl vent screen.
3. Remove cabin air filter. See **Fig. 1**.
4. To install cabin air filter, reverse order of removal. See **Fig. 1**.

2008 Ford Mustang

CABIN AIR FILTERS Cabin Air Filter - Mustang



Item	Part Number	Description
1	17D515	Wiper pivot arm nut covers (2 required)
2	W706109	Wiper pivot arm nuts (2 required)
3	175261/17527	Wiper pivot arms
4	N804837	Cowl vent screen pin-type retainers (4 required)
5	G046000094	RH cowl vent screen
6	G046000093	LH cowl vent screen

G00431902

Fig. 1: Cowl Vent Screen
Courtesy of FORD MOTOR CO.