


REMOVAL AND INSTALLATION

Fuel Tank and Filler Pipe — Exploded View



Item	Part Number	Description
1	9C335A	Fuel level sensor access cover
2	9C335A	Fuel pump (FP) module access cover
3	14A474	Fuel level sensor electrical connector

(Continued)

Item	Part Number	Description
4	14A474	FP module electrical connector
5	9J279A	Fuel supply tube quick connect coupling
6	9C385	Fuel level sensor lock ring
7	9J379A	FP module lock ring


(Continued)

REMOVAL AND INSTALLATION (Continued)

Item	Part Number	Description
8	9275	Fuel level sensor

(Continued)

Item	Part Number	Description
9	9H307	FP module



Item	Part Number	Description
10	13A516	Rear lamp harness retainer (6 required)
11	W525937	Fuel tank filler hose clamp
12	W710861	Fuel tank strap retainer pin (2 required)

(Continued)

Item	Part Number	Description
13	W710947-S439	Fuel tank strap retainer bolt (2 required)
14	9055A	Fuel tank strap (2 required)
15	9E325A	Vapor tube quick connect coupling

(Continued)

REMOVAL AND INSTALLATION (Continued)

Item	Part Number	Description
16	W506033	Fuel tank filler pipe retainer bolt
17	9034A	Fuel tank filler pipe
18	9002	Fuel tank

1. For additional information, refer to the procedures in this section.